

INCLUDE BIOSECURITY IN YOUR PERMIT TO WORK SYSTEM OR RULES FOR PERSONS
UNDERTAKING CONSTRUCTION ACTIVITIES ON YOUR SITE – EXTRACT FROM
AUCKLAND AIRPORT PERMIT TO WORK MANUAL

5.8 BIOSECURITY REQUIREMENTS

- 5.8.1 Auckland Airport is approved as a Place of First Arrival (“POFA”) for arriving international aircraft under the Biosecurity Act 1993. MPI specifies the standards and requirements which a POFA must adhere to. Works undertaken in the Aeronautical Zone also need to follow these MPI requirements.
- 5.8.2 All workers must follow Auckland Airport’s Biosecurity Rules available at Auckland Airport’s corporate website for airlines ([Downloads | Auckland Airport](#)) and in its on-line supplier portal for all service providers.
- 5.8.3 Key requirements from these rules affecting works in the aeronautical zone include:
- Only workers with legitimate cause for the purposes of their employment may enter Biosecurity Controlled Areas. In particular, workers who do not have any legitimate reason to be in the processing areas used by MPI to risk assess and process arriving passengers and airline crew and their baggage, cannot pass through these areas simply as a convenient exit route.
 - Workers must follow the directions of MPI Officers, particularly when within a Biosecurity Controlled Area such as the Arrivals Hall. This includes requests by MPI Officers for workers to leave or not enter a Biosecurity Controlled Area.
 - No uncleared baggage or other arriving items can be removed from any of the Biosecurity Controlled Areas without clearance from MPI.
 - No food which was taken from landside (eg, lunch) to the international Terminal Airside Area or the Airfield Airside Area can be taken back landside. It either needs to be consumed airside or disposed of in FOD/biosecurity bins before exiting airside. Food purchased in the international Terminal Airside Area must only be consumed airside and cannot be taken landside.
 - Construction sites must be managed so that they do not become a potential breeding habitat for exotic pests. This particularly includes the need to manage sites so that water does not pool becoming a breeding habitat for exotic mosquitos. Tyres, rubbish, equipment, construction materials, bins, and skips must all be managed so that water does not accumulate.
- 5.8.4 If a worker notices a pest (eg, cat, dog, Giant African Snail, insects coming from a ULD, water containing mosquito larvae, etc) then they should inform AOT (09 256 8990) or On-duty MPI Chief Quarantine Officer (09 909 8613) or MPI Duty Manager (09 909 8615).